

SOFTWARE ACTIVATION

Acquire 1.2 / M2M Panther

Table of Contents:

1. Introduction	3
2. Activate Acquire Software with a HL key (USB dongle)	3
2.1 How to install a new HL key	3
2.2 How to update your HL key	4
3. Activate Acquire Software with a SL key (Dematerialized protection)	5
3.1 How to install a SL key	5
3.2 How to update your SL key	6
3.3 How to rehost a license to another computer	7
3.3.1 How to access to the RUS tool:	7
3.3.2 Step one: on the machine where you wish to move the license	9
3.3.3 On the computer initially hosting the license	9
3.3.4 On the machine where you wish to move the license	10

1. Introduction

Two types of license option are available for Acquire software:

- HL key : an hardware-based protection key = USB dongle
- SL key : a software- based protection key = dematerialized license

To activate Acquire software please follow the steps described in the chapter dedicated to your license solution.

Important note: an administrator account is required to install or configure Acquire licence.

2. Activate Acquire Software with a HL key (USB dongle)

2.1 How to install a new HL key

Plug the USB dongle key on a USB 2.X port or USB 3.X port in the same computer which will be used to drive the PANTHER. Start Acquire software. That's it.

If you have started Acquire before plugging the USB dongle key, you will get this message:




Figure 1 - No license message


As explained in the message, insert the USB dongle key and click on the message to refresh the detection and display the Licences & Information panel.

If your hardware key contains a valid license, just close the panel and enter the software.

2.2 How to update your HL key

If you have purchased an extension time service plan or new options (features) for the software, you need to update your license.

- 1- Connect the HL key you want to update
- 2- Go to general settings



- 3- Go to the Licences & Information panel
- 4- Please make sure, your key is detected and selected (key highlighted in blue)




Figure 2 : Licences & Information : HL key

If you have already received your licence update file, please go to the step 7. On the contrary, follow the steps below:

- 5- Click on the button “Export key information”.
- 6- Add your Company Name to the C2V file : “ACQUIRE_C2V_<PC_hostname>_<Key ID>_<My Company Name>.c2v” and send it to: support-m2m@eddyfi.com
- 7- Once you receive the update file, go back to Licences & Information panel
- 8- Click on “Import license” and browse for your update file (.V2C). Click on Apply.
- 9- If the license file is correct, a message confirms the success of the update.




Figure 3 : confirmation message

- 10- Quit and re-start Acquire software

3. Activate Acquire Software with a SL key (Dematerialized protection)

3.1 How to install a SL key

1. Start Acquire from the shortcut on your desktop or by double clicking on C:\Acquire\Go_Acquire_US.bat. If you don't have any license activated on your computer, you will get this message:




Figure 4 - No license message

2. Click on the message to display the licenses & Information panel (it might take few seconds to display):




Figure 5 - Licences & Information panel - no license detected

This panel displays the detected licenses key and all the features included in all the detected keys. In the figure above, because no license is already installed, all the features are false (disable), and you cannot enter the software Acquire.

If you have already received your license update file, please go to the step 6. In the contrary, please follow the steps below:

3. Click on « Export fingerprint »
4. Add your Company Name to the C2V file : “ACQUIRE_C2V_<PC_hostname>_<My Company Name>.c2v” and send it to: support-m2m@eddyfi.com
5. Once you receive the update file, go back to Licenses & Information panel
6. Click on “Import license” and browse for your update file (.V2C). Click on Apply.
7. If the license file is correct, a message confirms the success of the update.





Figure 6 : confirmation message

8. Quit and re-start Acquire software

3.2 How to update your SL key

If you have purchased an extension time service plan or new options (features) for the software, you need to update your license.

- 1- From the home page, go to general settings



- 2- Go to the Licenses & Information panel
- 3- Please make sure, your key is detected and selected (key highlighted in blue)




Figure 7 : Licences & Information : SL key

If you have already received your license update file, please go to the step 7. In the contrary, please follow the steps below:

- 4- Click on the button “Export key information”.
- 5- Add your Company Name to the C2V file : “ACQUIRE_C2V_<PC_hostname>_<Key ID>_<My Company Name>.c2v” and send it to: support-m2m@eddyfi.com
- 6- Once you receive the update file, go back to Licenses & Information panel
- 7- Click on “Import license” and browse for your update file (.V2C). Apply it.
- 8- If the license file is correct, a message confirms the success of the update.




Figure 8 : confirmation message

- 9- Quit and re-start Acquire software

3.3 How to rehost a license to another computer

Once a software license is installed on one computer, it is possible to move it to another one. This operation is called a “Rehost” of the license and will use the “RUS” tool. The “rehost” operation needs three steps that are described below.

To enable the license on a new machine, this operation will disable the license on the initial machine

3.3.1 How to access to the RUS tool:

- 1- Install Acquire software
- 2- Start Acquire




Figure 9 - No license message

- 3- Click on the message to display the licenses & Information panel (it might take few seconds to display):





Figure 10 - Licenses & Information panel - no license detected

- 4- Click on "Rehost license (RUS)" to open the RUS tool



3.3.2 Step one: on the machine where you wish to move the license

- 1- Open the RUS as explained above
- 2- Got the "Transfer License" Tab
- 3- In the filed "Save recipient information to", select a location and a name for the identification file of this machine (*.id file)
- 4- Then, click on "Collect and save information". It will generate the *.id file



3.3.3 On the computer initially hosting the license

- 1- Open the RUS as explained above
- 2- **Keep the RUS open and close Acquire Software**
- 3- Copy the *.id file generated above
- 4- Open the RUS in the "Transfer License" Tab
- 5- In the menu "Read the recipient information file from", with the browser, select the location of the *.id file
- 6- In the menu "Generate the license transfer file to", with the browser, define a location for the license transfer (*.h2h file)
- 7- Then, click on "Generate License Transfer File"
- 8- The message below should appear



3.3.4 On the machine where you wish to move the license

- 1- Copy the *.h2h file generated above
- 2- Open the RUS in the “Apply License File” Tab
- 3- With the browser select the location of the *.h2h file and click on “Apply Update”
- 4- After that a message “Update written successfully” should appear

